

Enable Network-Provided Time

To get your Loop Player connected to the Internet, you may need to enable Network-Provided time.

Press 'Home' on your remote, and click 'Settings' from the home screen.


A screenshot of the Loop Player home screen. The background is dark gray. In the top left corner is the 'loop' logo in white. In the center, there are two white rounded rectangular buttons. The left button contains the text 'OPEN LOOP' and the right button contains the text 'SETTINGS'.

loop™


OPEN LOOP

SETTINGS

Click 'Device Preferences'.



Click 'Date & time'.



Click 'Automatic date & time'.

Date & time

Automatic date & time
Off

Set date
September 26, 2023

Set time
10:09

Set time zone
GMT-07:00 Pacific Daylight Time

Use 24-hour format
13:00

Click 'Use network-provided time'.

Automatic date & time

☒ Use network-provided time

☐ Off